

PŘEVODNÍ TABULKA ZAPALOVACÍCH SVÍČEK

(řazeno podle svíček Brisk)

BRISK	BOSCH	CHAMPION	NGK
B12YC		A5YC	P9EA9
B14YC	X5DC	A6YC	P8EA9
B15YC		A8YC	P7EA9
D12YC	F5DC		
D14Y	F6D		
D14YC	F6DC	C7YC	BCP7ES
D15Y	F7D		
D15YC	F7DC	C9YC	BCP6ES
D17Y	F9D		
D17Y	F8D		
D17YC	F8DC	C12YC	BCP5ES
D17YC	F9DC	C12YC	BCP5ES
DR12YC	FR5DC	RC6YC	
DR14YC	FR6DC	RC7YC	CPR7ES
DR15YC	FR7DC	RC9YC	CPR6ES
DR17YC	FR8DC	RC12YC	CPR5ES
DR17YC	FR9DC	RC12YC	CPR5ES
F14YC	D6BC	F7YC	AP7FS
F15YC	D7BC	F9YC	AP6FS
FR14YC	DR6BC	RF7YC	
FR15YC	DR7BC	RF9YC	APR6FS
G12YC	H5DC		
G14Y	H6D	BN6Y	
G14Y	H6D	BN7Y	
G14YC	H6DC	S7YC	BP7EFS
G15Y	H7D	BN9Y	
G15YC	H7DC	S9YC	BP6EFS
G17Y	H9D	BN12Y	
G17Y	H8D	BN12Y	
G17YC	H9DC	S12YV	BP5EFS
G17YC	H8DC	S12YV	BP5EFS
GR12YC	HR5DC	RS6YC	
GR14YC	HR6DC	RS7YC	BPR7EFS
GR15YC	HR7DC	RS9YC	BPR6EFS
GR17YC	HR9DC	RS12YC	
GR17YC	HR8DC	RS12YC	
J17		J17LM	
J19		J19LM	
JR17		RJ17LM	
JR19		RJ19LM	
K15YC	W7FS	J12YC	BP6S
K15YC	600CS	J12YC	BP6S
K17C	W8EC	J6(C)	B6S
K17C	W7EC	J6J	B6S
K17Y	W9F	J18(C)	BP5S

BRISK	BOSCH	CHAMPION	NGK
K17Y	W8F	J14Y(C)	BP5S
K19	W10E(C)	J11(J)	B-4
K19	W9E(C)	J8(C/J)	B-4
L08JW		N57R	B10EN
L08JW		N54R	B11EN
L08JW		N52R	B10EG
L08W	W07CS	N84G	B10EGW
L08W	W06CS	N82G	B11EGW
L10JW		N60R	B9EN
L10JW		N60R	B95EN
L10JW		N60R	B8EG
L12W	W3CS	N2G	B9EV
L12W	W2CS	N86G	B9EV
L12W	W2CS	N87G	B9EV
L12Y	W5D	N6Y	
L12Y	W5D	N63Y	
L12YC	W5DC	N6YC	BP8ES
L12YC	W5DC	N6YC	BP9ES
L14	W5C	N1	
L14	W4C	N2	
L14	W4C1	N3	
L14C	W5CC	N2C	B8ES
L14Y	W6D	N77Y	
L14Y	W6D1	N79Y	
L14YC	W6DC	N7YC	BP7ES
L14YC	W6DC	N279YC	BP7ES
L15	W7C	N4	
L15	W7C	N7	
L15	W7C	N288	
L15C	W7CC	N4C	B7ES
L15W	W5CS	N3G	B7EV
L15W	W4CS	N3G	B8EV
L15Y	W7D	N9Y	
L15YC	W7DC	N9YC	BP6ES
L15YC	W7DC	N28YC	BP6ES
L17	W8C	N5	
L17	W8C	N6	
L17C	W8CC	N5C	B6ES
L17W		N4G	
L17Y	W9D	N16Y	BP4E
L17Y	W8D	N14Y	BP4E
L17Y	W9D	N13Y	BP4E
L17Y	W8D	N12Y	BP4E
L17YC	W9DC	N14YC	BP5ES
L17YC	W8DC	N12YC	BP5ES
L17YC	W8DC	N11YC	BP5ES
L19	W9C	N8	B4E
L19C	W9CC		B5ES

BRISK	BOSCH	CHAMPION	NGK
LR12YC	WR5DC	RN6YC	BPR8ES
LR14YC	WR6DC	RN7YC	BPR7ES
LR15YC	WR7DC	RN9YC	BPR6ES
LR17YC	WR9DC	RN11YC	BPR5ES
LR17YC	WR8DC	RN11YC	BPR5ES
N08W	W07AS	L55G	
N08W	W06AS	L55G	
N12	W3AS	L3G	
N12	W2AS	L2G	
N12Y	W5B	L61Y	
N12YC	W5BC		BP8HS
N14	W5A	L78	
N14	W4A	L78	
N14	W4A1	L78	
N14	W3A	L78	
N14C	W5AC	L78C	B8HS
N14C	W4AC	L78C	B9HS
N14Y	W6B	L82Y	
N14YC	W6BC	L82YC	BP7HS
N15	W7A	L82	
N15	W7A	L85	
N15C	W7AC	L82C	B7HS
N15W	W5AS	L4G	
N15W	W4AS	L4G	
N15Y	W7B	L87Y	
N15YC	W7BC	L87YC	BP6HS
N17	W8A	L86	
N17C	W8AC	L86C	B6HS
N17W		L6G	
N17Y	W8B	L92Y	BP4H
N17Y	W8B	L95Y	BP4H
N17YC	W8BC	L92YC	BP5HS
N19	W9A	L88A	B4H
N19	W9A	L90	B4H
N19C	W9AC		B5HS
NR12YC			BPR8HS
NR15YC	WR7BC	RL87YC	BPR6HS
P15	WS5E	CJ4	BM7A
P15	WS7E	CJ6	BM7A
P15Y	WS5F	CJ6Y	BPM7A
P17	WS8E	CJ8	BM6A
P17	WS8E	CJ11	BM6A
P17Y	WS7E	CJ8Y	BPM6A
PR15Y	WSR5F	RCJ6Y	BPMR7A
PR17Y	WSR8F	RCJ7Y	BPMR6A
U15	HS5E	DJ6J	BM7F
U17	HS8E	DJ8J	BM6F